

# Wall Panel Installation Guideline

## Safety Instructions

Follow fixture, power tools instructions and user's manuals.  
Wear proper protective gear.

## Installation Instructions

### A. Cleaning the wall.

1. Clean and prep the installation surface, using sandpaper to remove excessive bumps or texture of the wall surface.
2. Use a clean cloth to clear the debris of each wall panel.
3. Use a leveler to make sure the starting panel is straight.

### B. Glue Straight onto the wall.

1. Apply construction adhesive in a "s" shape pattern to the back of the wall panel.
2. Push firmly against the wall, making sure all adhesive is coming into contact with the wall.
3. Repeat with the rest of the wall panels.

### C. Screw panels into the wall.

1. Use flat head screws to screw the wall panel directly into the wall through the acoustic felt. Make sure you screw the felt to the studs behind the drywall.
2. Please use the stud finder to find each center of the stud. They are normally 16" apart.
3. Please screw 24" vertically apart, and 16" horizontally.

### D. Screw panels with 2" battens.

1. If you have a concrete wall, please secure the 2" battens horizontally to the length of the accent wall.
2. Put the battens 24" apart vertically.
3. Use flat screws to screw the wall panels onto the 2" battens.
4. Please screw 24" vertically apart and 16" horizontally.

If the wall panels need to be cut-to-size. Please use a portable circular saw with a sharp blade (60-80 teeth). Use a utility knife to cut the felt only.